

ZMIN Label Printer MacOS Driver Setup Guide

一、Install printer driver


1、Download driver from web: www.zmin.com.cn,get the PPD file.




2、open System Preferences, click ”Printers & Scanners”




3、connect the ZMIN label printer,open the printer's power, click (+) when printer is ready.




4、select ZMIN printer, and choose a driver please select "other..."




5、location the PPD file



6、click “Add” button to add the printer’s driver.




7、finish the printer driver install.




二、Setup the printer's parameter.


1、open a pdf file, select "File"->"Print..."




2、select ZMIN label printer and correct paper size.




3、Select the default label size by the size of the actual label. If there is no desired size, select "Manage Custom Sizes"




4、Click "+" to add a custom label, use the ruler to measure the actual height and width of the label, fill in the "paper size" textbox, double-click "unnamed" can modify the name of the custom label, after the modification is complete Click "OK" to complete the custom label settings.




5、Click "Preview" at the bottom of the print direction, select "Printer Features"





6、In the printer features, you can set the printer's resolution, darkness, speed and so on.






7、After the parameters are set, click "Preset" and select "Save current settings as preset"





9、OK, now you can print the label from PDF file or other design software.





Attention:

You must make a paper calibration each time you change the label size, or it may be print incomplete (press and hold the "Feed" button for five seconds).